

PWR-RMT-RBT2-515R-LC

Quick Setup Tutorial

Part 1: Hardware Setup

Step 1: Connect the power cord to the PWR-RMT-RBT2-515R-LC and wall outlet.

Step 2: Connect the router power plug or another device's power plug to an outlet.

Step 3: Connect the LAN cable from the router to the port on the PWR-RMT-RBT2-515R-LC. The internet LED (green) will blink to show the internet is online.

Step 4: If you need UIS enabled (power cycles the router in case it fails), press and hold for 2 seconds the UIS On/Off button to activate internet protection.

NOTE: Press the UIS On/Off button only when the internet LED is blinking. If the internet LED is off, pressing the button may result in the unit performing an outlet reset.

Part 2: Utility Settings

Step 1: Insert the supplied CD into your computer and locate, install and launch the Utility application **OR** while in the same LAN as the device, open a browser and type <http://Outlet>

A dialog box will appear. The username is "admin" with password "admin".

Step 2: Launch the Web User Interface to access the settings.

Part 3: How to Access the Device from outside the LAN

There are two methods to remotely control the outlets:

A. Use an instant messaging tool like Google Hangouts (also available in the app store)

B. Web user interface (DDNS & Port Forwarding required)

Method A (Using Google Hangouts):

Step 1: Launch the Utility software to access the settings or if you know the IP of the device, enter it into the browser.

Step 2: In the configuration settings, click on *Hangouts*. Set the status to Online and input the Login ID and Password for a Google account.

Step 3: In the *Add Contact Accounts* enter another Google account (must be different). This account will be used to control the PWR-RMT-RBT2-515R-LC remotely.

Step 4: Once configured, make sure both Google accounts are setup to trust each other. In the Google privacy settings, make sure the settings are set to limited. Both accounts need to be able to see each other as online for it to work.

Step 5: Once added, you can control the device by chatting with it.

Step 6: Type "help". The Google account will respond with a list of available commands."

Method B (Using DDNS and setting Port Forwarding):

Step 1: Login to your router and port forward the PWR-RMT-RBT2-515R-LC IP address to port 80 on TCP.

Step 2: If you have a static IP, you can access the settings outside by using the IP. If you have a dynamic IP, you can use DYN.com or No-IP to register an account to get a free domain name.