

E-VSSR-10

Rugged Vibration Senor

- · Adjustable vibration alarm trip-point
- · Selectable over- or under-vibration alarm
- Adjustable alarm delay prevents false shutdowns
- Fail-Safe output permits alarm and shutdown control logic
- NPN output
- · Protects machinery and helps prevent costly downtime
- 24 Vdc power supply included
- NEMA 4X housing

Product Information

Description

E-VSSR-10 is an excellent choice as a compact and rugged stand-alone vibration sensor. It is engineered to protect industrial machinery against catastrophic failure associated with vibration levels above or below the trip point, which can be caused by imbalance, misalignment, looseness or excessive load. It mounts directly to the machine being monitored, allowing early detection of a pending malfunction, enabling cost-effective preventive maintenance.


The sensor has three LED indicators to provide the operator with at-a-glance output status as well as the circuit condition. The NPN output can be wired for machine shutdown or as part of an early warning system. An adjustable alarm delay prevents false alarms by allowing the user to set a minimum fault condition time before the output changes state, thus preventing needless system shutdowns during operation or startup.


The vibration sensor is housed in a cast aluminum NEMA 4X enclosure suitable for mounting directly to the measurement point of the machine being monitored. The compact size makes installation possible in tight spaces on virtually any type of machinery.


The E-VSSR-10 is ideal for detecting over- or under-vibration in machinery such as large motors, gearboxes, turbines, pumps, blowers, crushers, compressors, blenders, hammermills and conveyors.

Enclosure Dimensions

Operator Interface (cover removed)







The setting dials and switch are located under the housing cover. Remove the cover to change settings and replace when finished.

Installation

Orientation IMPORTANT: This vibration monitor senses vibration along the axis indicated by the SENSING DIRECTION arrow. Orient the vibration monitor with the arrow parallel to the vibration axis to be monitored.

Mounting Rigid, tight attachment is necessary for any vibration-sensing device. For this reason the **sensor** must be attached to a smooth, flat surface. Any looseness or rocking will permit error-causing resonance. Therefore, the **sensor** must be tightly and securely bolted to the measurement surface using <u>ALL</u> mounting tabs/holes.

Specifications

LED	Ind	ıca	to	rs

PowerVibration	Compared to the compared to th
Alarm	Red - output in alarm state
Settings/Ranges Alarm trip point	0.1 - 2.2 in/s rms 2.5 - 55 mm/s
Alarm delayAlarm	
Operational Limits (Vibration Min. frequency (-3db)	

Isolated NPN Output

Current	50 mA
V _{cF} (max @ 50 mA)	1.0 V
BV _{CFO} (breakdown volts)	100 V
P _D (max power overtemp)	100 m@W
1 _{ceo} (max leakage overtemp)	
Fail-Safe	Transistor ON when powered and not alarmed.
Terminals/Connections	10 Feet of 6 conductor, unshielded cable, 22 AWG
Enclosure	Cast Aluminum. NEMA 4X
Operating Temperature	
NPN option	-40°C to 85°C (-40°F to 185°F)
500 P P P	accessor was a W
Weight	0.75 lb (0.34 kg)

Power Requirements

Voltage	24 Vdc (18 - 30 Vdc)
Current (max)	30 mA @ 24 Vdc
(24 Vdc/130mA power sup	ply included)

Max. acceleration ± 50 g peak

Specifications subject to change without notice.